# Lawrence Berkeley National Laboratory

**LBL Publications** 

# Title

A Strategy for the Abandonment of Modified In-Situ Oil Shale Retorts

# Permalink

https://escholarship.org/uc/item/8k17j867

# Authors

Fox, J P Persoff, P Moody, M M <u>et al.</u>

# **Publication Date**

1978-11-01

# **Copyright Information**

This work is made available under the terms of a Creative Commons Attribution License, available at <u>https://creativecommons.org/licenses/by/4.0/</u>

Presented at the Environmental Control Symposium, Washington, D.C., November 28-30, 1978

# TWO-WEEK LOAN COPY

This is a Library Circulating Copy which may be borrowed for two weeks. For a personal retention copy, call Tech. Info. Division, Ext. 6782

RECEIVED LAWRENCE BERKELEY LABORATORY

LBL-8426

JAN 2 9 1979

LIBRARY AND DOCUMENTS SECTION

# and Environment Division

A Strategy for the Abandonment of Modified In-Situ **Oil Shale Retorts** 

J. P. Fox, P. Persoff, M. M. Moody, and C. J. Sisemore

Berkeley Laboratory University of California/Berkeley

## DISCLAIMER

This document was prepared as an account of work sponsored by the United States Government. While this document is believed to contain correct information, neither the United States Government nor any agency thereof, nor the Regents of the University of California, nor any of their employees, makes any warranty, express or implied, or assumes any legal responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by its trade name, trademark, manufacturer, or otherwise, does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency thereof, or the Regents of the University of California. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or any agency thereof or the Regents of the University of California.

## A STRATEGY FOR THE ABANDONMENT OF MODIFIED IN-SITU OIL SHALE RETORTS

J. P. Fox and P. Persoff Lawrence Berkeley Laboratory

M. M. Moody and C. J. Sisemore Lawrence Livermore Laboratory

## INTRODUCTION

In modified in situ (MIS) oil shale retorting, the resource is processed in the ground. Porosity is introduced into the formation by mining out from 20 to 30% of the in-place oil shale. This material is brought to the surface and either processed in surface retorts or stockpiled. The balance of the material is rubblized underground using various mining techniques. Oil is extracted by pyrolysis and combustion.

This process produces oil, a low BTU gas and process water and leaves behind large underground chambers (retorts) of spent shale and surface piles of raw or spent shale. The acceptability of MIS retorting may depend on the resolution of several environmental issues related to these residuals including groundwater disruption, resource recovery, retort stability and solid and liquid residual disposal.

The purpose of this paper is to investigate the feasibility of returning the solids stockpiled on the surface and process water to the abandoned underground chambers. We believe that potential environmental problems can be largely overcome by returning on-site waste materials to the abandoned underground retort. This would fill the void space created by mining, thus improving structural strength and reducing permeability to groundwater flow. If sufficient strength could be developed, it may be possible to design retorts so that the pillars could be retorted and resource recovery improved. It would also result in the simultaneous disposal of solid and liquid residuals.

### CONTROL STRATEGY

Various materials could be introduced into an abandoned retort or surrounding strata to increase structural strength or to reduce the flow of groundwater through the retort. These materials, called grouts, have been widely used in a number of fields including oil field reservoir engineering, nuclear waste containment, gas storage in underground formations, deep coal mining, soil consolidation and various construction activities. The nature of these conventional materials needs to be explored to determine the types of grouts that may be produced from on-site waste materials and properties required for retort sealing. Any grout used to seal an abandoned MIS retort should have the following characteristics:

- (1) The grouted area must be impermeable enough to prevent the degradation of local ground water or surface water.
- (2) The grouting material must be chemically stable in the presence of saline groundwater.
- (3) The grout viscosity must be low enough and the setting time long enough for the slurry to penetrate a large area.
- (4) The grouted area should be able to withstand both hydrostatic and overburden pressures. The hydrostatic pressure is due to natural head differences that exist between the aquifers surrounding the oil shale deposits in some areas and to significant dewatering during retorting.

An impressive array of commercially-available grouting materials has been used in other industries. These have been extensively described in the literature (1, 2) and include cement and chemical grouts. Cement grouts typically have long setting times, are non-Newtonian and have relatively high viscosities compared to chemical grouts. Chemical grouts are water solutions of various inorganic or organic compounds and are most typically based on sodium silicate, acrylamide, polyphenolic and urea-formaldehydes, lignins, and resins. Properties and cost factors for some of these grouts are compared with spent shale in Table 1. Preliminary estimates indicate that it could cost from 20 to 270 dollars per barrel of oil for the grouting material alone if abandoned retorts were sealed with these conventional materials. Spent shale grouts, on the other hand, may be economically feasible if technical problems associated with their use are resolved.

The high costs of conventional grouts and the on-site availability of some of the raw materials necessary to manufacture them, suggests that waste products be used to produce grouts. Readily available materials include raw and spent shale, latent heat within the retort, gases, process water and mine water. These materials should be considered as raw materials for on-site manufacture of grouts that would not be economically competitive if purchased from commercial sources. Many of these components show promise for use as grouting materials. Some possibilities include on-site conversion of raw or spent shale into a pozzolan or cement, use of NH<sub>3</sub> in the gas and process water to produce urea-formaldehyde polymers, use of  $CO_2$  in the gas and  $Na_2CO_3$  in the process water to produce insoluble carbonate deposits, and the manufacture of silica gels from mine water, retort waters or offgas.

There are many possible solutions to the retort abandonment problem using these on-site waste products. The most appropriate one will depend on desired strength increase, permeability reduction, retort/aquifer geometry and cost. The following sections of this paper will discuss the use of spent shale and process water as major components of a grout and methods of distributing the grout in the retort.

Class	Example	Viscosity before gelling, cp (range)	Gel time min. (range)	Cost factor relative to neat cement	Potential Application		
					Hydraulic barrier	Provide Struc- tural Strength	
						Medium	High
Cement	Portland cement slurry (neat)	(a)	10-300	1.0	x	x	x
Silicate	Water glass (sodium silicate)	1.5-2	0.1-60	1.3	x	x	x
·	Injectrol G (3)						
Polymer	AM-9 polyacrilamde (1)	1.2-1.6	0.1-300	7.0	x	x	x
	PWG (3)	1.5	->300	9.0	x	x	x
Resins	Herculox (3)	13	4-60	4.5	x	x	x
	Epseal (3)	80-90					
Emulsions	Asphalt 65% (4)				x		
Foams	Polyurethane foam (5)	:	15	1.5	x		
Spent shale	Lurgi (6)	(a)	28 days	0.05			
Lignin base	Blox-All (2)	8-15	3-90	1.65	x		
Unsaturated fatty acid	Polythixon FRD (2)	10-80	25-360		x		
Elemental sulfur		7 cp @ 159 C	sets when cool	available at low cost from gas refining sites			
Formaldehyde base	Urea-formaldehyde (2)	3.5-13	1-60	6.0	x		

Table 1. Comparison between conventional grouting materials and spent shale

(a) Depends on the water-cement ratio (WCR) and presence of additives. With a WCR of 45%, and no additives, the viscosity of neat cement is 200 cp. Addition of a slurry fluidizer (i.e., naphthalene polymer) may reduce this to 20 cp. By comparison, a WCR of 450% to 900% is needed to reduce the viscosity of Lurgi spent shale to 200 cp.

မှု

## SPENT SHALE AS A GROUT

Spent shale has been proposed as a grouting material (6) and as a strength-forming material (7). The chemical composition of spent shale is compared with pozzolans in Table 2. This comparison shows that spent shale appears to meet the chemical requirements for ASTM Class C pozzolan and is very similar to natural pozzolans. This is of considerable interest because the spent shale could be used to reduce permeability and provide strength development of an abandoned MIS retort.

Two studies have been conducted on the use of surface spent shale to manufacture a cement-like material. However, these have met with limited success (possibly due to low temperatures reached in the surface retorts). Culbertson, Nevens and Hollingshead (7) studied the stabilization of spent shale from a TOSCO retort. Shear strength and confined compressive strength in the range of 250 to 500 psi were obtained. Strength development was positively correlated with the amount of cohesive hydrates formed. After 15 days of setting, no loss of strength occured in samples resaturated with water.

Nevens, Habenicht and Culbertson (6) studied the filling of a simulated in-situ retort with a slurry of Lurgi spent shale. Samples calcined at 750 to 850 C required from 500 to 1000 wt % water to reduce the viscosity to 100 cp. Compressive strengths obtained after 28 days ranged from 5 to 200 psi.

Although results with 100% spent shale grouts have been discouraging to date, research is in its infancy and advances may occur. The most promising possibility is to use spent shale to create a hydraulic lime-pozzolan mortar. This is a mixture containing active lime (CaO) and pozzolanically active silica (SiO<sub>2</sub>) and alumina (Al<sub>2</sub>O<sub>3</sub>) which yield cohesive hydrates when mixed with water. This strategy is explored here by contrasting the chemistry of cements, pozzolans and mineralogical changes that occur during oil shale retorting.

## Cement, pozzolan and oil shale chemistry

The chemistry of pozzolan and cement and of the carbonate/silicate minerals in oil shale is germane to understanding the potential role of spent shale as a grout. Cements are prepared by blending proper proportions of finely ground limestone and clay and firing the mixture in a kiln at 1450 to 1550 C. The resulting clinker is cooled, about 5% to 6% gypsum is added as a set retarder and the mixture is pulverized. When water is added to this material and the paste is allowed to set it will gradually convert to a hardened product. This process can be represented by the following set of chemical equations:

## Calcining

Limestone or  $CaCO_3 \xrightarrow{\Delta} CaO + CO_2$  $Clay \xrightarrow{\Delta} Al_2O_3 + SiO_2 + Fe_2O_3$ 

(1)

(2)

	Oxide analysis, weight percent						
Constituent	typical typical industrial natural pozzolan (lignite pozzolan fly ash)		combustion run spent shale	ASTM C-618-78 class C pozzolan			
	(9)	(10)		(11)			
Si0 <sub>2</sub>	55.0	28.7	46.5	)			
A1203	17.7	12.0	10.7	) >50.0			
Fe203	3.5	6.8	4.2	) –			
Ca0	3.2	40.5	17.2	-			
MgO	1.0	7.4	7.8	-			
so <sub>3</sub>	-	2.5	_	<5.0			
Fe0	.0.9	_		-			
к <sub>2</sub> 0	6.4	-	3.0	-			
Na <sub>2</sub> 0	3.4	0.6	3.3	• –			
Loss on ignition	6.3	0.4	1.6	<6.0			

Table 2. Composition of pozzolans and spent shale

σī

Formation of Clinker Compounds

$$3Ca0 + Si0_2 \xrightarrow{\Delta} 3Ca0 \cdot Si0_2$$
 (3)

$$2Ca0 + SiO_2 \xrightarrow{\Delta} 2Ca0 \cdot SiO_2$$
(4)

$$3Ca0 + Al_2 O_3 \xrightarrow{\Delta} 3Ca0 \cdot Al_2 O_3$$
(5)

$$4\text{Ca0} + \text{Al}_2\text{O}_3 + \text{Fe}_2\text{O}_3 \xrightarrow{\Delta} 4\text{Ca0} \cdot \text{Al}_2\text{O}_3 \cdot \text{Fe}_2\text{O}_3 \tag{6}$$

Hydration

$$2(3CaO \cdot SiO_2) + 6H_2O \longrightarrow 3CaO \cdot 2SiO_2 \cdot 3H_2O + 3Ca(OH)_2$$
(7)

$$2(2CaO \cdot SiO_2) + 4H_2O \longrightarrow 3CaO \cdot 2SiO_2 \cdot 3H_2O + Ca(OH)_2$$
(8)

$$3Ca \cdot Al_{2}O_{3} + 16H_{2}O + CaSO_{4} \cdot 2H_{2}O \longrightarrow 3CaO \cdot Al_{2}O_{3} \cdot CaSO_{4} \cdot 18H_{2}O$$
(9)

$$3Ca0 \cdot A1_{2}O_{3} + 26H_{2}O + 3CaSO_{4} \cdot 2H_{2}O \longrightarrow 3CaO \cdot A1_{2}O_{3} \cdot 3CaSO_{4} \cdot 32H_{2}O$$
(10)

It would not be economically feasible to manufacture cement on site because of the high energy requirements (8). However, a hydraulic limepozzolan could be produced at temperatures much below clinkering temperatures.

Pozzolans are siliceous and aluminous materials that react with lime in finely divided form and in the presence of moisture to form cohesive hydrates. These hydrates are the main strength-giving compounds of hydrated cement. Typical pozzolanic reactions are:

$$2SiO_2 + 3Ca(OH)_2 \longrightarrow 3CaO \cdot 2SiO_2 \cdot 3H_2O$$
(11)

$$A1_{2}O_{3} + 4Ca(OH)_{2} + 10H_{2}O \longrightarrow 3CaO \cdot A1_{2}O_{3} \cdot Ca(OH)_{2} \cdot 18H_{2}O$$
(12)

These equations show that if active silica and alumina react with lime, calcium silicate and calcium aluminate hydrates are formed. These compounds are similar to those that give strength to portland cement. The ability of a siliceous or aluminous material to react at normal temperature as shown is called "pozzolanic activity" and is measured by ASTM Method No. C 311-77 (11). A sufficient degree of pozzolanic activity may be present in spent shale or it may be increased by heat treatment, or by modifying retorting conditions, or by lime addition.

If pozzolanic activity could be induced in surface spent shale by modifying retort operating conditions, it may be possible to manufacture a hydraulic lime-pozzolan on site. This is more attractive than formation of a cement since activation of silica and alumina takes place at lower temperatures than the formation of clinker compounds (900 - 1000 C). For maximum development of cementitious properties, additional lime may be required. This could be added before retorting or afterward. Fine grinding of the spent shale would be required. Because the clinker compounds of portland cement, formed in equations (3) through (6), would not be present, the grout would set more slowly and have a lower final strength. The feasibility of this strategy depends on the mineralogical changes that occur during the surface retorting process. The effect of oil shale retorting on the mineralogy of spent shale has been studied by Campbell (12, 13). He found that three principal carbonate/silicate reactions occur during oil shale retorting. First, dolomite  $(Ca(Mg_x, Fe_{1-x})(CO_3)_2)$  decomposes around 600 C to produce iron and magnesium oxides and calcite (CaCO<sub>3</sub>). Calcite decomposes to calcium oxide and carbon dioxide between 700 and 950 C depending on the partial pressure of CO<sub>2</sub>. Above 1000 C the calcium oxide reacts with silica to produce calcium silicate compounds (3CaO·SiO<sub>2</sub>, 2CaO·SiO<sub>2</sub>) and other

 $Ca(Mg_{x}, Fe_{1-x})(CO_{3})_{2} \xrightarrow{\Delta} (1-x)FeO + xMgO + CaCO_{3} + CO_{2}$ (13) 2FeO + CO<sub>2</sub>  $\xrightarrow{\Delta}$  Fe<sub>2</sub>O<sub>3</sub> + CO (14)

nonreactive compounds (gehlenites and akermanites). These reactions are

$$CaCO_{3} \xrightarrow{\Delta} CaO + CO_{2}$$

$$nCaO + mSiO_{2} \xrightarrow{\Delta} Ca_{n}Si_{m}O_{(n+2m)}$$
(15)
(16)

The temperature at which these reactions occur is very important in considering the use of oil shale as a cementitious material. Most surface retorts operate at less than 600 C, which is too low to form a mixture of active silica and active alumina with cementitious properties. Therefore, if spent shale is to be produced for use as a grouting material, the surface retorting process may have to be optimized for pozzolan formation as well as for oil yield.

Based on the foregoing, we propose that the surface retort be operated to produce a hydraulic lime-pozzolan mixture. This recommended strategy is summarized in Figure 1. This figure shows pozzolan production and additives that are being explored in an experimental program. The surface retort is operated to produce a hydraulic lime-pozzolan. The effect of additions of limestone, portland cement and slurry fluidizer are being investigated. The limestone addition would enhance the availability of lime to form cohesive hydrates. If strength of the lime-pozzolan mixture is inadequate, a small addition of portland cement may be desirable. The portland cement would contribute tricalcium (3CaO·SiO<sub>2</sub>) and dicalcium (2CaO·SiO<sub>2</sub>) silicate, which, upon hydration, yield Ca(OH)2 and cohesive hydrates. The spent shale pozzolan would react with the Ca(OH)<sub>2</sub> as it is formed to yield additional cohesive hydrates as shown in equations (11) and (12). The slurry fluidizer would decrease the viscosity of the slurry so that it could be more easily distributed in the abandoned retort.

ð

### GROUT DISTRIBUTION

summarized as (12):

Grout distribution in abandoned retorts will depend on several factors including grout properties, retort properties and emplacement geometry. Most commercial grouting is performed by point injection from small diameter pipes placed in a grid pattern on centers less than 20 feet apart. This would not be economically feasible due to the large number of deep holes that would have to be drilled. Well spacing greater than or equal to 70 feet




Figure 1. Recommended strategy for abandonment of MIS retorts

- <sup>a</sup> Add limestone before retorting if retorting temperature is high enough to calcine limestone.
- <sup>b</sup> Add calcined limestone after retorting if retorting temperature is not high enough to calcine limestone.
- <sup>c</sup> Portland cement addition only if strength development without it is inadequate.

would be needed to make grouting attractive as a method of spent shale disposal if drilling were done from the surface. The effects of the geometry of the grout emplacement, the retort permeability and grout viscosity on retort groutability need to be studied.

Viscosity is the most important grout property for distribution. Spent shale slurries investigated to date have typically had viscosities of 500 to over 1000 cp at low water contents (100% by weight water added) (6). These slurries have generally had viscosity reduction to 50 cp at 200% by weight water added but some slurries have required 1000% by weight water to obtain viscosities less than 100 cp (for comparison, the viscosity of water is 1 cp at 20 C). The relative penetrability of spent shale grout will be strongly dependent on obtaining a low viscosity product (< 50 cp) at low water content (100% by weight water) to achieve desired strength development and permeability reduction.

Permeability of the spent in-situ retort will be the most important property for grout distribution. Uniform penetration of a particulate grout (e.g. spent shale-based grout) may be difficult to achieve because of the heterogeneous nature of the void space of an abandoned in-situ retort. It includes large voids between rubble fragments (up to one inch and more), fine voids where oil shale has been fractured but fragments have not moved apart, fissures and cracks in retort walls, and minutes pores created in spent shale by pyrolysis of kerogen. Invasion of only the larger pores may not be adequate to reduce permeability.

Effective grouting may require complete and uniform penetration of most voids. This will be controlled by the relative size of particles in the grout and the void space in the rubble. In order to penetrate a retort at a reasonable pressure and flow rate, the size of the largest suspended particle should not be greater than about one-third of the size of the voids. Typically, particulate grouts are used for openings that are 1/16 inch or larger and chemical grouts are used for openings that are less than 1/16 inch. Therefore, two injections may be required to seal an abandoned in-situ retort. The first would use a grout with a relatively large particle size and the second would use a nonparticulate grout.

Point source grout injection may not be very effective for grout distribution in abandoned retorts. The grout penetration from a point source is severely limited by the high headloss developed near the tip of the pipe. For most commercial grouts however, set up time is short and point sources are used because not enough grout penetration occurs prior to set up for the well point headloss to become a problem. However, for abandoned retorts, this configuration is not suitable as a large number of injection ports would be required. The cost for this may be excessive. Therefore, line source placement should be explored.

Line source injection is beneficial for increased rubble penetration and faster grout distribution but it is limited by the size of the pipe available to deliver the grout and head required to push the grout through the rubble. A 36 inch pipe diameter flowing at 2 ft/sec could deliver 14 cfs of grout to the rubble. If this grout were delivered to a slotted section approximately 50 feet in length, approximately 8 hours would be required to fill the corresponding 50 foot section of a commercial size retort. Setup time could be important for this approach.

## SUMMARY

This paper considered the production of a hydraulic lime-pozzolan mixture from spent shale produced in surface oil shale retorts. This mixture could be slurried with process effluents and pumped into abandoned MIS retorts. This control strategy would simultaneously provide for long-term retort stability, minimal groundwater disruption, enhancement of resource recovery and disposal of process residuals. Work completed to date and some theoretical considerations suggest that surface retorts can be operated to produce a spent shale with pozzolanic properties. Additions of limestone, portland cement and slurry fluidizer may be required. Additional work is required to determine optimum retort operating conditions and required additives, and to resolve a number of technical problems. Preliminary cost estimates indicate that this would be an economically viable strategy if technical issues could be resolved. These include high grout viscosities, high water-solid ratios, poor strength development and grout distribution within an abandoned retort. If spent shale grout or some other low-cost on-site waste material cannot be reclaimed for retort filling and plugging, it is possible that MIS retorting may not be both environmentally and economically viable due to the high costs associated with other control strateg-However, if the constraint of enhanced resource recovery is relaxed ies. and if it can be demonstrated that creep and subsidence are not long-term problems, then other lower-cost control strategies may be considered. These would address only the groundwater disruption issues and would include leaching, mine design modifications, grout curtains, and chemical immobilization of leachables.

### REFERENCES

- 1. Joe Herndon and Tom Lenehan, <u>Grouting in soils</u>, Vol. 1. State of the Art Report, Federal Highway Administration Report No. FHWA-RD-76-26, June 1976.
- Joe Herndon and Tom Lenehan, <u>Grouting in soils</u>, Vol. 2. Design and operating manual, Federal Highway Administration Report No. FHWA-RD-76-27, June 1976.
- 3. Halliburton Services, Inc., Duncan, Oklahoma, "Halliburton Pressure Grouting Service", 1971, promotional publication no. PGS-0059.
- 4. Carl T. Brandt and William R. Bowles, U. S. Patent No. 3,159,976, "Sealing of porous and fissures formations with cationic asphalt emulsions", December 8, 1964.
- 5. J. H. Black, "Polyurethane foam a useful new borehole grout", Journal of Hydrology, 32, 1977, p. 183-188.
- 6. T. D. Nevens, C. H. Habenicht and W. J. Culbertson, Jr., "Disposal of spent shale ash in "in situ" retorted caverns", report by Denver Research Institute to Rio Blanco Oil Shale Project, May 1977.
- William J. Culbertson, Jr., Thomas D. Nevens and Robert D. Hollingshead, "Disposal of shale ash", Quarterly of the Colorado School of Mines, Vol. 65, No. 4, October 1970, p. 89.
- P. K. Mehta, "Energy, resources and the environment a review of the U. S. cement industry", World Cement Technology, July-August 1978, p. 144.
- 9. R. Turriziani, "Aspects of the Chemistry of Pozzolans", in H. F. W. Taylor, ed., <u>The Chemistry of Cements</u>, v. 2, London, Academic Press, 1964, p. 71.
- Oscar E. Manz, "Utilization of Lignite Fly Ash", in <u>Technology and Use</u> of <u>Lignite</u>, Bureau of Mines Information Circular 8304, USDI Bureau of Mines, 1966, p. 68.
- 11. <u>1978 Annual Book of ASTM Standards</u>, Part 14, Philadelphia, American Society for Testing and Materials.
- 12. J. H. Campbell, "The kinetics of decomposition of Colorado oil shale: II, carbonate minerals", UCRL-52089, part 2, March 1978.
- 13. J. H. Campbell and J. R. Taylor, "Effects of steam on oil shale retorting: a preliminary laboratory study", UCID-17770, April 1978.

This report was done with support from the Department of Energy. Any conclusions or opinions expressed in this report represent solely those of the author(s) and not necessarily those of The Regents of the University of California, the Lawrence Berkeley Laboratory or the Department of Energy.



. .

.

TECHNICAL INFORMATION DEPARTMENT LAWRENCE BERKELEY LABORATORY UNIVERSITY OF CALIFORNIA BERKELEY, CALIFORNIA 94720